



### Mounted Hair Brushes

Code: **SKF**

Mounted Hair Brushes facilitating polishing process and not requiring extra tool. These brushes form the perfect surface with fine micron Diamond Compounds at final polishing.

Shank: 3 mm  
Ø 22 x 2 mm



Order: **SKF022**

Shank: 3 mm  
Ø 16 x 8 mm



Order: **SKF168**

Shank: 3 mm  
Ø 16 x 8 mm



Order: **SKF016**

Shank: 3 mm  
Ø 6 x 8 mm



Order: **SKF068**



GT-133

### Plexiglass Polishing Sticks

Code: **PC..**

It becomes a precision Diamond File when used with Diamond Compounds. GT-133 is a suitable holder for tool usage.

Order Code	Dimension	Type
PC.08	8 x 8 x 150 mm	Square
PC.10	10 x 6 x 150 mm	Rectangular
PC.13	13 x 6 x 150 mm	Rectangular
PC.06	Ø 6 x 150 mm	Round
GT-133	Holder (suitable for tool usage)	



### Wooden Tools

Code: **ASK**

Code: **AC..**

It is suitable to polish with Wooden Felts at narrow and radius areas of moulds, areas unsuitable to use polishing stones.

#### Mounted Wooden Points

Order Code	Dimension
ASK.06	Ø 6 x 15
ASK.10	Ø 10 x 20
ASK.15	Ø 15 x 25
ASK.20	Ø 20 x 30
ASK.010S	Ø 10 (spherical)

#### Wooden Lapping Sticks

Order Code	Dimension	Type
AC.06	6 x 6 x 150	Square
AC.10	10 x 10 x 150	Square
AC.12	12 x 12 x 150	Square
AC.03	6 x 3 x 150	Rectangular
AC.13	13 x 6 x 150	Rectangular
AC.20	20 x 8 x 150	Rectangular
ACS.6	Ø 6 x 150	Round
ACS.8	Ø 8 x 150	Round



### Diamond Compounds

Code: **SDP**

Our Diamond Compounds have been formulated using a blend of high quality diamond grit, polisher chemical mixture and herbal oil. It is highly concentrated. Reasonable price and in box packaged as 20 g. syringe. From rapid stock removal process to final polishing process, it cleans EDM traces in hard areas by removing burrs (stock removal). Our Diamond Compounds are soluble in both oil and water. During operation, the compound may get lumpy / dry, in this case, it can be moisturised with 1-2 drops of Diamond Compound Moisturiser (order code: SDS200).

Order Code	Micron (µm)	Approx. Mesh	Package	Application
SDP.01	<b>0 / 1</b>	#60.000	20 g.	Final Polishing
SDP.02	<b>2 / 1</b>	#14.000	20 g.	
SDP.03	<b>3 / 2</b>	#8.000	20 g.	
SDP.05	<b>5 / 3</b>	#4.000	20 g.	
SDP.07	<b>7 / 5</b>	#3.000	20 g.	Pre-polishing
SDP.10	<b>10 / 7</b>	#1.700	20 g.	
SDP.14	<b>14 / 7</b>	#1.500	20 g.	
SDP.20	<b>20 / 14</b>	#1.100	20 g.	
SDP.28	<b>28 / 20</b>	#800	20 g.	Rapid Stock Removal
SDP.40	<b>40 / 28</b>	#550	20 g.	
SDP.60	<b>60 / 40</b>	#500	20 g.	

**Application:** Application is usually done with circular movements. During operation, cleaning is very important and it absolutely should be done at every stage. The sequence should be followed from coarse to fine micron. Polishing tools for each micron compound should be specified and should be used only at that micron, absolutely don't mix with other micron compounds. For cleaning of mould surface, our "Cleaning Spray" (order code: W170104) is an effective, economic and provide easiness. As a surface protector, you can choose our "Protective Wax Spray" (order code: W160106).

### Diamond Compound Moisturiser

Order Code: **SDS200**

During operation, the compound may get lumpy / dry, in this case, it can be moisturised with 1-2 drops of Diamond Compound Moisturiser.

Package: 200 g.



### Metal Polisher Paste

Order Code: **MARPOL**



Metal work pieces lose their gloss in time and can be oxidized. In this case, Metal Polisher Paste cleans surfaces and purifies from rust and dirt's. It is a very good dirt remover, it does not remove burrs and only cleans and polishes. **Package:** 200 g.