




Code: G92C (steel type)

Wear Plate, AFNOR / ISO 9183-2

Form A - B - C - D - E - F - G - H - I


Code: G92



A	l	b	l1	l2	l5	Hole	Form
70	100	20	50	-	45	2	A
	150	10			45	3	B
	200	20			95	4	D
100	150	50	50	25	70	4	C
	200			95	4	D	
	250			145	5	E	
150	200	100	50	-	95	4	D
	250				145	5	E
100	100	30	25	25	32.5	3	F
	300	50	50	-	145	6	G
150	100	25	50	-	45	4	H
	150		25	50	70	4	I
	300		100	50	-	145	6
200	100	50	50	-	45	4	H

Order: G92 or G92C. A x l


* G92: Bronze + self-lubricating type.
* G92C: Steel type.
* Fixing screws: M10.



Wear Plate, VDI 3357


Self-Lubricating / Two-Way Sliding Type
Form: A - B

Code: G96




Order: G96. A x l x h x Form

A	l	l1	l2	l3	c	h	d	d1	t	Form		
25	110	85	25	-	12.5	-0.02	H13	H13	+0.5	A		
	120	95				12	15	9	8.5			
	110	85				15	18	11	10.5			
	120	95										
60	125	100	25	-	30	30	20	13.5	13	A		
	150	125										
	160	135										
60	200	100	25	175	30	40	20	13.5	13	B		
	125	100		-						A		
	150	125		-						A		
	160	135		-						A		
	200	100		175						B		



Wear Plate, CNOMO

Code: G93



* Fixing screws: M10.

Order: G93. A x l

A	l	l1	l2	l3	b	a3	Hole	Form
50	63	39	12	-	20	15	2	B
50	160	126	21	-	12	19	2	B
50	250	100	21	116	12	19	3	C
63	100	18	15	34	39	12	4	A